ITEL, 5603 Wireless Handset

> IP-DECT System (Global) User Guide



#### **NOTICE**

The information contained in this document is believed to be accurate in all respects but is not warranted by Mitel Networks™ Corporation (MITEL®). The information is subject to change without notice and should not be construed in any way as a commitment by Mitel or any of its affiliates or subsidiaries. Mitel and its affiliates and subsidiaries assume no responsibility for any errors or omissions in this document. Revisions of this document or new editions of it may be issued to incorporate such changes.

No part of this document can be reproduced or transmitted in any form or by any means - electronic or mechanical - for any purpose without written permission from Mitel Networks Corporation.

#### **Trademarks**

Mitel is registered trademark of Mitel Networks Corporation.

Other product names mentioned in this document may be trademarks of their respective companies and are hereby acknowledged.

IP-DECT System (Global)
Mitel 5603 Wireless Handset User Guide
December 2011

®,™ Trademark of Mitel Networks Corporation
© Copyright 2011, Mitel Networks Corporation
All rights reserved

About Your Phone	1
Description of Your Handset	2
Features and Functions	
Chargers	
Contacting Emergency Services	
Tips for your Comfort and Safety	
Frequency Range	
Exposure to Radio Frequency Signals	
Chemical Resistance	
Icons and Text in the Display	
Keys and Buttons	
Navigation Key	
Sound off Key	
Key Lock, and Upper/Lower Case Key	
Soft Keys	9
Volume Button	10
Alphanumeric Keys	10
Headset	
Customizing Your Phone	12
Switch the Handset On/Off	
Turn the Audible Signal On/Off	
Lock/Unlock the Keypad	
Lock/Unlock the Keypad in Idle Mode	
Lock/Unlock the Keypad during a Call	
Lock/Unlock the Handset	13
Making and Answering Calls	14
Make a Call	
Pre-Dial	
Dial a Number from the Call list	
Dial a Number from the Local Phonebook	
Dial a Name from the Central Phonebook	14
Dial a Number from the Company Phonebook	
Answer a Call	15
Answer a Call	
End a Call	15
During a Call	
Adjust the Volume during a Call	
Open Contacts during the Call	16

Turn the Microphone on/off during a Call	
Call Handling	7
Hold	8
Transfer1	
Conference	
Answer Call Waiting	
Callback1	
Call Park1	9
Advanced Features	0:
Call Forward	0:
Call Pickup	0:
Do Not Disturb	1:1
Direct Page2	1:1
Group Page2	1:1
Loudspeaker Page	1:1
Voice Mail	2
Receive a Voice Mail	2
Check the Voice Mail Inbox	2
Contacts	'3
Navigate the Menu	
Enter/Exit the Menu Mode	
Menu Tree	
Calls	
Contacts	
Settings	
In Call Marry	
Call Menu          2          2          2          2	
Missed Calls	
Call Time	0
Contact Menu	0
Call Contact	
Edit Contact	
Contact Menu       .3         Call Contact       .3         Edit Contact       .3	80 80 81

Central Phonebook
Settings Menu32
Sound and Alert Settings32
Select Headset Profile
Display Settings
Time & Date Settings
Phone Lock settings
Answering
Change the Menu Language
Change Owner ID         36           In Charger         36
System
System
Advanced Functions
Admin Menu
Clear Lists in Charger
System Handling
Software Upgrade and Additional Features
Troubleshooting
Operation Notice
Accessibility and Voice Quality42
Maintenance
Maintenance of Batteries43
Battery Warnings43
Charge the Battery43
Replace the Battery43
Attach the Hinge-type Clip
Attach the Swivel-type Clip45
Easy Replacement
Before Starting Easy Replacement Procedure
Easy Replacement Procedure46
Related Documents
Index

## **About Your Phone**

The Mitel 5603 Wireless Handset is a feature-rich handset designed to operate in conjunction with an IP-DECT base station and the 3300 ICP. It is ideal for users who need mobile voice and messaging functions.




Figure 1: 5603 Handset

Caution: The handset/headset must be fully charged before starting regular use.

## Description of Your Handset

1	Earpiece speaker	
2	Soft keys  The three soft keys is used with GUI, that is, the functions of each Soft key is indicated by text in the display just above the keys.	
3	Off-hook key  To answer a call, to pre-dial a number, and as a short cut to the Call list.	
4	Voice mail access* A quick access to the handset's Voice mail.	
5	Key lock and Upper/Lower case Combined key lock and Upper/Lower Case.	
6	Space To add space between text.	
7	Microphone	
8	Sound off key  To turn on/off audible signals in idle mode, silencing the ring signal at incoming call, and to turn the microphone on/off during a call.	
9	Tactile indicators  There are two tactile indicators to indicate the centre of the key pad.	
10	On-hook and On/Off key  Combined button; to end a call, to return to standby mode, and to switch the handset on/off by long press.	
11	Four-way navigation key  Navigation key with Left, Right, Up, and Down.  During a call, the keys Up and Down are used to increase and decrease the speaker volume, respectively.	
12	Display The B/W display is 28 mm wide and 35 mm high with backlighting.	
13	Headset connector  The headset connector is for connecting a headset. The connector is protected against dust by using the headset connector cover.	
14	LED Indicates incoming call, messaging, low battery, and charging.	

<sup>\*</sup>System dependent feature

#### Features and Functions

IMPORTANT: The handset may retain small magnetic objects around the mouth cap or ear cap region.

#### Case

The plastic cover parts are made of durable PC/ABS material.

#### Antenna

The antenna is integrated inside the handset.

#### Loudspeaker

The handset has a separate loudspeaker for the Loudspeaking function. It is located on the back side of the handset.

#### Microphone

The microphone is placed on the front bottom side of the handset.

#### Clip

There are two different belt clip options for the handset: a hinge-type clip (standard), and a swivel-type clip. You use the clip to attach the handset to a pocket or belt. You can use the handset without a clip on. See "Attach the Hinge-type Clip" on page 44, or "Attach the Swivel-type Clip" on page 45.

#### **Battery**

The battery is a rechargeable Li-Lon battery, placed under a battery cover. See "Replace the Battery" on page 43.

The battery is fully charged within four hours. See "Charge the Battery" on page 43.

#### Chargers

#### Desktop Charger




Figure 2: Desktop Chargers

There are two desktop chargers available: a basic one that will only charge the handset, and one with advanced functionality to download new software and to synchronize options. The handset is fully operational while placed in the charger.

The charger is delivered with a plug-in power supply and is connected into an ordinary wall socket. For more information. See the *5603/5604/5607 Programmer Installation and Maintenance Guide.* 



**Note:** Only use the charger within the temperature range of  $+5^{\circ}$  C  $- +40^{\circ}$  C.

Caution: Only use the provided power supply. See the 5603/5604 Programmer Installation and Operation Manual.

#### Rack Charger

The 5603/5604 charging rack has been replaced with a new charging rack that charges six 5603/5604/5607/5624 handsets simultaneously. The rack charger charges handsets, synchronizes options and downloads software.

The rack charger can charge up to six handsets simultaneously and synchronize options. For more information. See the 5603/5604/5607/5624 Rack Charger Installation and Operation Guide.

#### Contacting Emergency Services

This handset, like any wireless phone, communicates using radio signals. As with any wireless phone, you may not be able to establish a connection under all conditions; therefore, you should not rely solely on a wireless telephone for essential, emergency communication. The key lock feature disables the handset keypad and prevents the accidental dialing of numbers that may result in nuisance calls. It also prevents accidental calls to emergency services numbers like 911, 999, or 112.

To disable the key lock feature, press the \* key and then press **Select**.

Currently, mobile IP phones do not support Enhanced 911 (E911) operation. If emergency services are required, it is necessary to keep the system administrator and location database up-to-date.

#### Tips for your Comfort and Safety

#### Don't cradle the handset!

Prolonged use of the handset can lead to neck, shoulder, or back discomfort, especially if you cradle the handset between your ear and shoulder. If you use your phone a lot, you may find it more comfortable to use a headset. See the section on headset use for more information.

#### Protect your hearing

Your phone has a control for adjusting the volume of the handset receiver or headset. Because continuous exposure to loud sounds can contribute to hearing loss, keep the volume at a moderate level.

#### Frequency Range

The handset is a radio transmitter and receiver. When it is on, it receives and sends out radio frequency (RF) energy. The handset operates on different frequency ranges depending on market and employs commonly used modulation techniques:

EU	1880-1900 MHz
USA/CAN	1920-1930 MHz
LA	1910-1930 MHz
BR	1910-1920 MHz
	1900-1920 MHz

#### Exposure to Radio Frequency Signals

This equipment complies with FCC radiation exposure limits set forth for an uncontrolled environment. This device complies with FCC SAR limit of 1.6 W/kg. The maximum SAR value measured when used at the ear, and when worn on the body using belt clip is as follows:

	SAR values
Head	0.043 W/Kg
Body worn	0.037 W/Kg

This device must not be co-located or operating in conjunction with any other antenna or transmitter.

Use of non-Mitel approved accessories may violate the FCC RF exposure guidelines and should be avoided.

#### **Environmental Requirements**

- Only use the handset in temperatures between 0° C to +40° C (32° F to 104° F).
- Avoid exposing the handset for direct sunlight or close to other heat sources.
- Avoid volume levels that may be harmful to your hearing. Exposure to excessive sound pressure from a handset's earpiece or headset may cause permanently hearing loss.
- Do not expose the handset to open flame.
- Keep the handset away from excessive heat and moisture.
- Avoid sudden temperature changes to prevent condensation in the handset. It is recommended to put the handset into an air tight plastic bag until the temperature is adjusted, for example, when entering or leaving a cold/heated building on a warm/cold day.
- Protect your handset from aggressive liquids and vapors.
- The handset may retain small metal objects around the mouth cap or ear cap region.
- Keep the handset away from strong electromagnetic fields.
- Do not place a cold handset in a charger.

#### Chemical Resistance

The alpha and numeric characters printed on the exterior of the handset have been tested and found resistant to chipping, fading or wearing off when the handset is treated with common cleaners and disinfectants or perspiration. The following chemicals have shown no harmful effect:

- 3% Hydrochloric Acid
- M-alcohol (70% Methylated Ethanol)
- 60% Chlorhexidin 0.5mg/ml

Acetone can be damaging to the plastic casing of the handset and should not be used.

## Icons and Text in the Display

All functions and settings available to the user are shown as icons and text in the display. The icons and text in the display indicate functions and settings to which you have access. The

display normally displays date and time, the Owner ID and handset number. The Owner ID can manually be set by the user.




Figure 3: Display Configuration in Standby Mode

The Status bar (1) is used for icons which give the user information about signal strength, missed calls, new messages, phone lock, key lock, sound off, time and battery status. This row is always visible in all screens.

The Header bar (2) displays the current date, headset connection, and system connection.

The Active area (3) is used for information such as the name of the system to which the handset is connected. A user identity provided from the system and/or an Owner ID can also be displayed if configured in the Settings menu. This is also the area for window text, for example "missed calls", or to confirm an action.

The Scroll bar (4) is placed to the right of the "Active area". It becomes visible when a menu screen has more than six menus, or if the complete text in a message cannot be displayed on the screen simultaneously.

The Soft key bar (5) is used for soft keys which can be used as short cuts for functions in the handset. See the *Mitel 5624 Wireless Handset Configuration Guide*.

#### **Icons**

.ul	"Signal strength" icon is visible in the upper left corner. The staples shown in display depends on the signal strength.	
	"Full battery" icon appears in upper right corner.	
	The "Low battery" icon appears when the battery has 10% or less remaining capacity left. In addition; a warning signal sounds every minute, the LED flashing orange, and the window "Battery low. Charge now!" appears.	
	The "Empty battery" icon is flashing when the battery has 5% or less remaining capacity left. In addition; a warning signal sounds every second, the LED flashing red, and the window "Battery empty. Shutting down." appears.	
*	"Sound off" icon appears when the Sound off key is pressed, and when the handset, with the in charger function "Sound off" enabled, is placed in a charger.	

<b>%</b>	"Microphone off" icon indicates a silenced microphone. It appears after a long press on the Sound off key during a call.	
◁	"Loudspeaking" icon appears in the soft key bar during a call. Pressing this icon will turn on the loudspeaker.	
Ø	"Loudspeaking off" icon appears after the soft key for Loudspeaking icon has been pressed. Pressing this icon will turn off the loudspeaker.	
3	"Key lock" icon indicates a locked keypad.	
a	"Locked entry" icon indicates that the contact cannot be edited or deleted by the user.	
<u>a</u>	"Phone lock" icon indicates a locked handset.	
Û	"Headset" icon indicates that a corded headset is connected to the handset.	
<b>@+</b>	"Outgoing call" icon is added to all outgoing calls in the call list.	
Q+	"Incoming call" icon is added to all answered calls in the call list.	
gt	"Missed call" icon is added to all missed calls in the call list.	
U	"Missed call" icon is added in the status bar. This icon remains until the "Call list" is opened.	
1;	"PDM/WSM communication" icon is visible when handset is communi-cating with PDM/WSM via advanced charger.	
مه	"Voice mail" icon indicates that new voice mail has been received.	
Menu icons		
	The "Contacts" menu contains all names/numbers in the local phonebook. In addition, a company phonebook with up to 500 entries can be downloaded to the phone via the PDM. you can to access a central phonebook* from the "Contact" menu.	
	The "Calls" menu contains call lists, call time, and call services*. Call services is configured in the PDM.	
	The "Settings" menu contains personal handset settings such as changing the ringer volume, selecting language, etc.	

<sup>\*</sup> This feature is system dependent.

### **Keys and Buttons**

Some keys have different functions depending on the phone state or the length of time that you press a key.

**Short press** = Press and release the key in less than one second.

**Long press** = Press and hold down the key for longer than one second and then release.

#### Off-hook Key



This key is used to answer calls, to pre-dial numbers and as a short cut to the Call list. One short press in standby mode opens the call list.

#### On-hook, and On/Off Key



This key is used to disconnect calls and return to the main screen. A long press in standby mode switches the handset on/off.

#### **Navigation Key**



Use this key to step in the menu, and when working in text mode.

◀, ▶, ▲ , and ▼ are used for stepping left/right and up/down in the menu.

### Sound off Key



A long press on the Sound off Key in idle mode toggles between ring signal on/off. When you receive an incoming call, a long press on the key silences the ring signal. During a call, a long press on the key changes between microphone on/off.

### Key Lock, and Upper/Lower Case Key



This key locks the keypad in combination with the soft key "Lock". It is also used for switching between upper/lower case and digits.

304

### Soft Keys




Figure 4: Soft Keys

The three soft keys are located just beneath the display. The function of each soft key is indicated by text in the display just above the keys.

In idle mode, the soft keys can be used for specific functions defined by the user of the handset.

#### Volume Button

▲ and ▼ on the Navigation key are used for increasing/decreasing the earpiece, headset, and the loudspeaker volume.

#### Alphanumeric Keys




Figure 5: Available Characters



**Note:** Depending on the selected menu language, other characters can be available. This means that the character order can differ from the table above.

#### In standby mode, and number input mode

- A short press on a key enter the digits "0" "9" and the characters \* and #.
- Enter a pause in number input mode by a long press on the # -key. A pause is indicated by a "P" in the display.
- A long press on the \* key changes the tone sender on.
   Tone sender on is indicated by a "T" in the display.
- The keys "0", "2" "9" can be used for speed dialing. Press and hold any of the keys to access a contact beginning with a specific letter. For example, to access a contact beginning with the letter "A", press and hold the key "2" and then press "Call" to speed dial.

#### In text input mode

- A short press on a key 0-9, displays the first available character on that specific key. The
  marked character is selected after a timeout, or when another key is pressed.
- To change to upper/lower case, press the \* key before entering the character. The \* key can also be used to display only the digits.
- To add space in the text, make a short press on key 0.

- The first character entered when adding/editing a name in the Contacts menu, will be an upper level character followed by lower level characters, unless the \* key is pressed before entering the character. To switch between Abc, ABC, abc, and 123 the \* key is pressed.
- A long press on the #-key displays special characters.

#### Headset

f you will use your handset frequently, we recommended you use a headset so you have both hands free. The headset comes in two versions: microphone integrated in the cable and microphone on a boom.

In order to achieve optimal audio quality with your headset we recommend you select the corresponding headset profile. See the *Mitel 5607 Wireless Handset Configuration Guide* for more information.

The default setting is microphone on a boom; that is, the audio is optimized for using a headset with microphone on a boom. You can change the headset profile in the menu as follows:

- **1.** Enter the menu by pressing the "Menu" soft key.
- 2. Select "Settings".
- 3. Press "Select".
- 4. Select "Headset".
- **5.** Select the corresponding headset profile from list.
- 6. Press "Select".

If the pre-configured headset profiles do not match the headset in use, or the audio performance is poor, you can configure an own headset profile in the PDM. See the *Mitel 5603 Wireless Handset Configuration Manual*. You can select profiles configured in the PDM using the handset menu.

## **Customizing Your Phone**

#### Switch the Handset On/Off

The handset is switched off:

- 1. Press and hold On-hook key [5]. When pressing the On-hook key, the handset will vibrate and the display lights up.
- 2. A window "Switch on" appears. Confirm by pressing "Yes".

The handset is in idle mode:

- 1. Press and hold On-hook key [35].
- 2. A window "Switch off" appears. Confirm by pressing "Yes".

## Turn the Audible Signal On/Off

A long press on the in idle mode, changes between ring signal on/off.

The icon indicates a silenced handset.

## Lock/Unlock the Keypad

#### Lock/Unlock the Keypad in Idle Mode

To prevent accidentally pressing keys and making a call, the keys can be locked.

#### Lock Keypad

Press \*\* and then "Lock".

#### Unlock Keypad

Press \* and then "Yes".



Note: You can answer/close an incoming call while the keypad is locked. If configured in the RDM contact to " in the PDM, you can to call an emergency call while the keypad is locked. See the Mitel 5603 Wireless Handset Configuration Manual.

#### Lock/Unlock the Keypad during a Call

To prevent accidentally pressing keys you can lock them during a call. This can be useful when a headset is used and the handset is attached to a pocket or belt.

#### Lock keypad

- 1. Press \*\* .
- 2. Press "Lock".

#### Unlock keypad

- 1. Press \*\*
- 2. Press "Yes".

#### Lock/Unlock the Handset

You can protect the handset from unauthorized use. If you enable this function, you must enter a PIN code to switch on the handset to answer calls. You can change the default phone lock code (0000) to any 4 - 8 digit personalized code.

- 1. Press "Menu".
- 2. Select "Settings"
- 3. Select "Locks".
- 4. Select "Phone lock".
- 5. Select "Auto phone lock".
- 6. Select "On", "On in charger", or "Off".
- **Note:** If configured in the PDM, you can call an emergency call while the handset is locked. See the *Mitel 5603 Wireless Handset Configuration Manual*.

## Making and Answering Calls

#### Make a Call

#### Pre-Dial

- 1. Enter the number.
- 2. Press or "Call" to get the line. The number is shown on the display while dialling.


If required, press "Clear" to erase the number. You can use the Navigation key to step and add/delete a digit in the middle of a number. You can turn on the tone sender in a pre-dialled number by making a long press on  $\sqrt{*}$ ?

#### Dial a Number from the Call list

- 1. Press when in idle mode; or press "Menu", select "Calls" and then select "Call list".
- 2. Select a number.
- 3. Press or "Call" to dial. The number can be edited before the call is started. Press "More" and select "Edit number".

#### Dial a Number from the Local Phonebook

- 1. Press the "Menu" soft key.
- 2. Select "Contacts".
- 3. Select "Call contact".
- 4. Select contact from list, or search name/number by entering characters in the "Search" field.
- 5. Press or "Call" to make the call.



#### Dial a Name from the Central Phonebook<sup>1</sup>

- 1. Press the "Menu" soft key.
- 2. Select "Contacts".
- 3. Select "Central phonebook".
- 4. Select "Search by name".
- 5. Enter the first name and/or last name, the whole name does not have to be entered.
- 6. Press "Search".
- 7. Press or the "Call" key to make the call.

<sup>1.</sup> This is a system dependent function.

#### Dial a Number from the Company Phonebook

- 1. Press the "Menu" soft key.
- 2. Select "Contacts".
- 3. Select "Call contact".
- 4. The local and company phonebook appears in the same list but the company names are indicated by a "Locked entry" icon 🖺 in front of the name. Select contact from list, or search name/number by entering characters in the "Search" field.
- 5. Press or the "Call" key to make the call.



**Note:** you can to access the Company phonebook by pressing the soft key • III in idle mode.

#### Answer a Call

The flashing LED, accompanied by a ring signal and/or a vibrating handset, notifies you of calls. The ring signal and vibrator can be disabled. The calling party's handset number or name is shown. The name will be shown if the calling party's handset number is stored in the local phonebook. When a headset is connected to the handset, the answering button on the headset can be used to answer the call.

Other answering methods can be specified in the Settings menu. See the *Mitel 5603 Wireless Handset Configuration Guide*. The answering methods are Automatically and Loudspeaking.

When "Automatically" is enabled, all incoming calls will be connected automatically.

#### Answer a Call

When the signal sounds press to answer the call, or press the 🗓 soft key to answer the call in loudspeaking mode. The name/number of the calling party appears if calling line information is available.

#### End a Call

Press to end the call. The duration of the call is shown in the display. The total time of the call can also be retrieved from the Calls menu > Call time.

## **During a Call**



**Note:** Some of these functions are system dependent. The options are set up in the Portable Device Manager (PDM). See the *Mitel 5603 Wireless Handset Configuration Manual* and *Portable Device Manager (PDM) Installation and Operation Manual*.

If configured in the PDM/WSM, you can call an emergency call while the handset/ keypad is locked. During the ongoing emergency call, the soft key "More" and the soft key "R" are disabled.

#### Adjust the Volume during a Call

On the navigation key, press ▲ and ▼ to increase and decrease the volume, respectively. The handset will now store and keep the new volume level.

#### Open Contacts during the Call

- 1. Press the "More" soft key during the call.
- 2. Select "Contacts".
- 3. Press "Select".
- **4.** Select "Call contact" for searching a local or company phonebook contact, or select "Central phonebook" for searching a central phonebook contact.
- 5. Press "Select".
- 6. Select or search contact.



**Note:** You can call the selected contact by pressing "Call". When calling the contact, the first call will be put on hold. See also "Start a New Call during Conversation" on page 16.

#### Turn the Microphone on/off during a Call

- 1. Press the "More" soft key during the call
- 2. Select "Microphone off"
- 3. Press "Select".

The kicon indicates a silenced microphone. This means that the other part in an ongoing call cannot hear you. To turn the microphone back on, do as follows:

- 1. Press the "More" soft key during the call.
- 2. Select "Microphone on".
- 3. Press "Select".

#### Start a New Call during Conversation

- 1. Press the "More" soft key during the call.
- 2. Select "New Call" 1.
- 3. Press "Select".
- **4.** Enter number, or press **★ (E)** to access the phonebook.
- **5.** Press .

<sup>1.</sup> Visible if defined in the PDM.

## Call Handling

During a call, you may need to use the following features: Hold, Transfer, Conference, Call Swap, Callback, Call Park, and so forth.

You access these features by pressing the **More** soft key during a call. This displays the **In Call** menu (see below).




Figure 6: Accessing Features

You can also use these features by pressing the **R** key on the handset during a call. The table below lists the **In-Call** Menu features and the associated feature access code method.

In-Call Menu under More	Associated Feature Access Code
Contacts	
Microphone off	
New Call	R
Hold/Retrieve	R
Release	R4
Call Swap	R2
Join	RR + *80
Call Backl	5
Answer Call Waiting	R2
Call Park	RR + *7#

#### Hold

- 1. During a call, press the "More" soft key.
- 2. Select "Hold/Retrieve" to put the call on hold.

#### To retrieve the Held Call

- 1. Press the "More" soft key
- 2. Select "Hold/Retrieve" to retrieve the call.

#### Transfer

- **1.** During the call, press the "More" soft key.
- 2. Select "New Call".
- 3. Dial the number to which you want to transfer the call and then press the "Call" soft key.
- **4.** Do one of the following:
  - to make a blind transfer, select "Release" to hang up and connect the other two parties.
  - to make a supervised transfer, wait for an answer, announce the transfer, and then select "Release" to hang up and connect the other two parties.
  - to terminate the transfer and return to the held call, press "More" and then select "Call Swap".

#### Conference

To conference with another party during an active call:

- **1.** During a call, press the "More" soft key.
- 2. Select "New Call" to put the current call on hold.

- 3. Dial the number of the third party.
- 4. Wait for an answer.
- **5.** Press "More" and then select "Join" to conference all the parties together.

## **Answer Call Waiting**

While on a call, you hear a call waiting beep.

- **1.** Press the "More" soft key.
- 2. Press "Answer Call Waiting" to answer the incoming call.

#### Callback

Callback lets you request that the system notify you when a busy extension becomes free.

- 1. When a number/extension is busy, press the "More" soft key.
- 2. Select "Call Back" to set up the callback.
- 3. Your extension will ring when the called extension becomes free and automatically dial the extension back.

#### Call Park

The Call Park feature allows you to place a call in a special hold state. You, or someone else, can then retrieve the call from any extension in the system. After parking the call, the system can automatically connect you to paging equipment so that you can announce the call to the requested party.

To park an active call:

- 1. During the call, press the "More" soft key.
- 2. Select "Call Park".
- 3. Dial the directory number on which to park the call
- 4. Inform the called party of the waiting call.

To retrieve a parked call:

- 1. Press "Call".
- 2. Press "Call Services".
- 3. Select "Call Park Retrieve" and enter the directory number on which the call is parked.

## **Advanced Features**

The following features are available from the "Calls -> Call services" menu:

- Call Forward
- Call Forward Cancel
- Do Not Disturb
- Do Not Disturb Cancel
- Call Pickup
- Call Park Retrieve
- Direct/Group Page
- Loudspeaker Page

To access the Call Services menu:

- 1. Enter the menu by pressing the "Menu" soft key.
- 2. Select in the menu.
- 3. Press "Select".

#### Call Forward

To set Call Forwarding:

- 1. Press the "More" soft key.
- 2. Select "Call Forward".
- 3. Enter the extension number to which you want to forward your calls.
- 4. Press "Call".
- 5. Listen for a confirmation tone and then hang up.

To cancel Call Forwarding:

- 1. Press the "More" soft key.
- 2. Select "Call Forward Cancel".
- **3.** When you hear a re-order tone, press of to hang up. Forwarding is cancelled.

## Call Pickup

To answer a call that is ringing at another station in your Pickup Group:

- 1. Press the "More" soft key.
- 2. Select "Call Pickup".
- 3. Answer the call.

#### Do Not Disturb

To activate Do Not Disturb:

- 1. Press the "More" soft key.
- 2. Select "Do Not Disturb".
- 3. When you hear a re-order tone, press () to hang up.

To deactivate Do Not Disturb:

- 1. Press the "More" soft key.
- 2. Select "Do Not Disturb Cancel".
- **3.** When you hear a re-order tone, press  $(\mathfrak{F})$  to hang up.

### **Direct Page**

Direct Paging allows you to page a party through the party's handsfree speaker.

- **1.** Press the "More" soft key.
- 2. Select "Direct/Group Page".
- 3. Dial the extension number.
- **4.** Announce the page.

## **Group Page**

Group Paging allows you to page a group of telephones through their built-in speakers.

- 1. Press the "More" soft key.
- 2. Press "Direct/Group Page".
- 3. Do one of the following:
  - To page your prime page group, press #.
  - To page a specific page group, dial the page group directory number.
- 4. Speak to the dialed party after the tone.

## Loudspeaker Page

- 1. Press the "More" soft key.
- 2. Press "Loudspeaker Page".
- 3. Dial the paging zone number, if required.
- **4.** Wait for ringback and announce the page.



Note: Ask your Administrator for the paging zone number.

## Voice Mail

#### Receive a Voice Mail

When a new voice mail is received, the message alert signal sounds, and the voice mail icon appears in the status bar. The new voice mail notification is also displayed in a window.

#### Check the Voice Mail Inbox

Check the voice mail(s) by pressing "Call" from the window. If "Close" is selected, you can dial the Voice Mail by a long press on digit key "1" when in standby mode.

Follow the given instruction in the Voice Mail.



**Note:** In case the following message is shown: "Voice mail number not defined", the voice mail number needs to be configured to the voice mail button. Contact your system administrator.

## Contacts

The handset has a local phonebook with 250 entries, where names and numbers freely can be added, deleted, and edited by the user. The phonebook lists all names in alphabetical order, where three numbers can be added for each contact, that is, work number, mobile number, and other number.

For more information on how to add, edit, or delete a contact. See "Contact Menu" on page 30.

In addition, a company phonebook with up to 500 entries can be downloaded to the phone via the PDM. See "Software Upgrade and Additional Features" on page 39. The company phonebook name and numbers cannot be edited or deleted by the user. The phonebook lists all names in alphabetical order.

The local and company phonebook appears in the same list but the company contacts are indicated by a "Locked entry" icon  $\Box$  in front of the name. The company contact includes work number only. See "Dial a Number from the Company Phonebook" on page 15 for more information. The local and company phonebook can also be accessed by pressing the soft key  $\blacksquare$  in idle mode.

you can to access a central phonebook<sup>1</sup>. See "Dial a Name from the Central Phonebook" on page 14. The user then sends a request to a messaging server with the first characters entered, and the messaging server will return a list of names and numbers that matches the search.

<sup>1.</sup> This is a system dependent function.

## Navigate the Menu





Figure 7: Main Menu

- Settings (1)
- Contacts (2)
- Calls (3)

#### Enter/Exit the Menu Mode

Enter the menu by pressing the Menu soft key. The most recently used tab is highlighted. If the handset has been restarted, the Contacts tab appears.

- 1. Use the Left or Right navigation key to choose a menu tab and then press the Down navigation key to open it. The menu title appears and the first alternative is highlighted.
- 2. Use the Up or Down navigation keys to move through the list. Press the Right navigation key to select an alternative.



To back up in Menu mode:

- If you entered the menu using the Right navigation key, you can use the Left key to back up one step.
- If you entered the menu using the Menu soft key, use the **Back** soft key to back up.
- Press the **Menu** soft key again to exit the Menu and return to standby mode.

## Menu Tree


The following diagrams illustrate the menus for each tab.




**Note:** Some options are system-dependent and may not appear on your phone.

## Calls





# Contacts =




<sup>\*</sup> System dependent



**Note:** you can to access the Call contacts menu by pressing the soft key ◆ in idle mode.

# Settings **E**




### In Call

The In Call menu can be reached during an ongoing call by pressing the "More" soft key



**Note:** If configured in the PDM/WSM, you can call an emergency call while the handset/keypad is locked. When calling from a locked handset you can access the Microphone on/off function only from the In Call menu. During an ongoing emergency call you cannot access the In Call menu.



<sup>\*</sup> Visible if enabled/defined in PDM/WSM

#### Call Menu

- 1. Enter the menu by pressing the "Menu" soft key.
- 2. Select in the menu.
- 3. Press "Select".

#### Call List

The 25 last received, dialled or missed calls are stored in a call list. If a number occurs more than once the last time stamp, together with the total number of occurrences, is shown.



**Note:** If supported by the system, the number's contact name can be displayed in the call list.

Select "Call list", and step with ▲ and ▼ to scroll in the list.

The "Call list" can also be opened by pressing in idle mode.

#### Dial number from Call list

- 1. Select a number to call.
- 2. Press "Call" to dial.

#### View the Time of a Call

- 1. Press "More".
- 2. Select "Time of call". The time and date appears.

#### Edit Number from Call list

- 1. Press the "More" soft key.
- 2. Select "Edit number".

#### Save Number

- 1. Press the "More" soft key.
- 2. Select "Save number".

#### Delete Entry from the Call list

- 1. Press the "More" soft key.
- 2. Select an entry to delete.
- 3. Select "Delete".
- 4. Select "Yes" to delete the entry from the list.

#### Delete all Entries from the Call list

- 1. Press the "More" soft key.
- 2. Select "Delete all".
- 3. Select "Yes" to delete all the entries from the list.

#### Missed Calls

- 1. Select "Missed calls".
- 2. Step with the ▲ and ▼ to scroll in the list.
- 3. Press "Call" to call back.

As in "Call list" there is a "More" soft key which can be used to view the time/date of the call, edit the received number, add to contacts, and delete received numbers. See "Call List" on page 29 for information about the functionality in the "More" soft key.



Note: If supported by the system, the number's contact name can be displayed in the list.

#### **Call Time**

The total time of the previous call and last call appears by selecting "Call time".

#### Contact Menu

- 1. Enter the menu by pressing the "Menu" soft key.
- 2. Select 🖭 in the menu.

#### Call Contact



**Note:** Is it also possible to access Call contact by pressing the soft key • in idle mode.

- 1. Select "Call contact".
- 2. Select contact from the list, or enter name or number in the search field.
- 3. Press , or "Call".

you can to edit the contact by selecting "View" > "More". Note that it is not possible to edit a company phonebook contact. The company contacts are indicated by a "Locked entry" icon  $\Box$  in front of the name.

#### Add Contact

1. Select "Add contact".

#### Add New Contact


- 1. Select "New".
- 2. Select "Add", and enter the name of the contact. See "Alphanumeric Keys" on page 10.
- 3. Press "OK".
- 4. Select "Work number", "Mobile number", or "Other number".
- 5. Press "Add".
- **6.** Enter the numbers. you can add tone "T" or pause "P" in phone numbers by pressing the Space key 5 times or 7 times, respectively.

- 7. Press "OK".
- 8. Press "Save" and then "Back".

#### Add from Call List


- 1. Select "From call list".
- 2. Select a number.
- 3. Press "Add".
- 4. Select "Work number", "Mobile number", or "Other number".
- 5. Press "Select".
- 6. Press "Add", and enter name for the contact. See "Alphanumeric Keys" on page 10.
- 7. Press "OK".
- 8. Press "Save".

#### **Edit Contact**



- 1. Select "Edit contact".
- 2. Select contact, and press "Edit" twice.
- **3.** Enter new name/number. See "Alphanumeric Keys" on page 10. You can add tone "T" or pause "P" in phone numbers by pressing the Space key 5 times or 7 times, respectively.
- 4. Press "OK".
- 5. Press "Save".

#### **Delete Contact**



- 1. Select "Delete contact".
- 2. Select a contact.
- 3. Press "Delete".
- 4. Press "Yes" to confirm.

#### Central Phonebook

In the central phonebook you can search by name or number. The last search result can be displayed.

When the search result appears, you can view contact information, and add the number to new contact by pressing the "More" soft key. you can to dial the number by pressing , or the "Call" soft key.

1. Select "Central phonebook".

#### Search by Name

- 1. Select "Search by name".
- 2. Enter first name and/or last name.
- 3. Press "Search". The search result will be displayed.

#### Search by Number

- 1. Select "Search by number".
- 2. Enter the number.
- 3. Press "Search". The search result appears.

#### View Last Search Result

Select "Last result". Only the last result will be displayed.

# Settings Menu

- 1. Enter the menu by pressing the "Menu" soft key.
- 2. Select in the menu.

# Sound and Alert Settings

#### Adjust the Ringer Volume

- 1. Select "Sound & Alerts".
- 2. Select "Volume".
- 3. Adjust the volume by using ▲ and ▼ on the navigation key.
- 4. Press "Back" to save the setting.

#### Select Ring Signals

- **1.** Select "Ring signals".
- 2. Select "Internal call", "External Call", or "Callback"<sup>1</sup>.
- 3. Press "Select".
- **4.** Select ring signal. You can listen to the selected ring signal by pressing the "Play" soft key. The ring signal will be repeated until the "Stop" soft key is pressed.
- 5. Press "Select".

#### Turn the Vibrator on/off

- 1. Select "Vibrator alert".
- 2. Select "On", "On if silent" (i.e. the vibrator is on when the handset is muted), or "Off".
- 3. Press "Select".

<sup>1. &</sup>quot;Callback" is only applicable if defined in the PDM/WSM.

4. Press "Back" to save the setting.

## Set the Key Sound

This means that every time a key is used, a low sound is heard.

- 1. Select "Key sound".
- 2. Select "Silent, "Click", or "Tone".
- 3. Press "Back".

You can listen to the key sound by pressing the "Play" soft key.

#### Select Headset Profile

- 1. Select "Headset".
- 2. Select "Mic on boom", "Mic on cable", or "Customized headset profile" 1
- 3. Press "Select".

# **Display Settings**

- 1. Select "Display".
- 2. Select "Contrast".
- 3. Adjust the contrast by using the ▲ and ▼ on the navigation key.
- 4. Press "OK".
- 5. Press "Back".

## Time & Date Settings

#### Set Time Format

- 1. Select "Time & Date"
- 2. Press "Select".
- 3. Select time format. The actual time format will be displayed. Selectable time formats:
  - hh:mm (am/pm) (for example: 1:00pm)
  - hh:mm (for example 13:00)
- 4. Press "Select" to save the setting.

#### Set Date Format

- 1. Select "Time & Date".
- 2. Press "Select".
- 3. Select "Date format"

 $<sup>1. \ &</sup>quot;Customized \ headset \ profile" \ is \ only \ visible \ if \ the \ headset \ profile \ has \ been \ configured \ in \ the \ PDM/WSM.$ 

- 4. Press "Select". Date formats:
  - DD/MM/YYYY, for example: 17/09/2008 (also called Europe)
  - MM/DD/YYYY, for example: 9/17/2008 (also called US)
  - YYYY-MM-DD, for example: 2008-09-17 (ISO 8601)
  - MMM DD YYYY, for example: Sep 17 2008
  - DD MMM YY, for example: 17 Sep 08DD.MM.YYYY, for example: 17.09.2008
  - DD-MM-YYYY, for example: 17-09-2008
- **5.** Press "Select" to save the setting.

## Phone Lock settings

#### Activate the Automatic Key lock

- 1. Select "Locks".
- 2. Select "Automatic key lock".
- 3. Select "On" for activation of automatic key lock.



**Note:** You can answer/close an incoming call while the keypad is locked. If configured in the PDM/WSM, you can to call an emergency call while the keypad is locked. See the *Mitel 5603 Wireless Handset Configuration Manual*.

#### Activate the Phone Lock

The handset can be protected for unauthorized use. If this function is activated, a PIN code has to be entered at power on, or when the handset is placed in a charger - this behaviour will first be activated when the handset is placed in the charger. The default phone lock code (0000) can be changed to any 4-8 digit personalized code.



**Note:** If configured in the PDM/WSM, you can call an emergency call while the handset is locked. See the *Mitel 5603 Wireless Handset Configuration Manual*.

- 1. Select "Locks".
- 2. Select "Auto phone lock".
- 3. Select "On", or "On in charger".
- 4. Enter a PIN code.
- 5. Press "OK".

If the PIN code is forgotten it can be removed by your distributor.

#### Deactivate the Phone Lock

- 1. Select "Locks".
- 2. Select "Auto phone lock".
- 3. Select "Off".

- 4. Enter a PIN code.
- 5. Press "OK".

#### Change PIN Code

- 1. Select "Change PIN code".
- 2. Enter the old PIN code.
- 3. Press "OK".
- 4. Enter new PIN code twice.
- 5. Press "Save".

## Answering

The default setting for the handset is to use the Off-hook key when answering a call. The answering behaviour can be configured to answer the call automatically, i.e. without pressing a key, and/or in loudspeaking mode. you can to set the answering behaviour to any key. If "Any key" is selected, any keys except the "On-hook" key and the "Sound off" key can be used to answer a call.

#### Answering Key

The answering key is by default set to Hook-off.

- 1. Select "Answering".
- 2. Select "Answering key".
- 3. Select "Hook-off" or "Any key".
- 4. Press "Back" to save the setting.

#### Answering Behaviour

- 1. Select "Answering".
- 2. Select "Answer behaviour".
- 3. Select "Automatically" and/or "Loudspeaking".
- **4.** Press "Change" to change the setting. The check box will be marked.
- **5.** Press "Back" to save the setting. To remove the setting, press "Change". The check box will be unmarked.

#### Change the Menu Language

- 1. Select "Language". English, Español (Spanish), Français (French), Nederlands (Dutch), Deutsch (German), Russki (Russian).
- 2. Press "Back".



**Note:** You can download one additional language via the PDM/WSM. See "Software Upgrade and Additional Features" on page 39. 7 languages are available for download; Czech, Greek, Hungarian, Polish, Russian, Slovakian, and Turkish.

## Change Owner ID

The Owner ID is set to identify the handset.

- 1. Select "Owner ID".
- 2. Enter in identity.
- 3. Press "Save".

### In Charger

#### Redirect Calls while Charging

Calls can be redirected to another extension when the handset is placed in a charger. The function is automatically cancelled when the handset is removed from the charger.

- 1. Select "In charger".
- 2. Select "Redirect".



**Note:** The settings in the system determines how the incoming calls will be handled. This is a system dependent feature.

#### Switch off While Charging

When the handset is placed in the charger it can be switched off. When removed from the charger it will switch on again.

- 1. Select "In charger".
- 2. Select "Switch off".

#### Mute Handset While Charging

When the handset is placed in the charger it can be muted while it is charging. When it is removed from the charger it will switch on the sound again.

- 1. Select "In charger".
- 2. Select "Sound off".

## Deactivate the Charging Mode

- 1. Select "In charger".
- 2. Select "No action".

## System

# Change System

Select "Automatic" or a specific system. If the handset is set to "Automatic" it selects a system according to the priority list. See "Priority" on page 37.

#### Subscribe System

The handset can subscribe up to eight different systems. To subscribe a new system, the "Park:" (Portable Access Right Key) and "Ac:" (Authentication code) related to the system that will be log on to are required. Contact your system administrator for more information.



**Note:** The PARK code may not be required if there is no alien DECT system within the coverage area.

The IPEI code is a unique code which has been assigned to the handset. See also "Admin Menu" on page 38.

- 1. Enter System name. Press "next".
- **2.** Enter PARK code. The PARK code may not be required if there is no alien DECT system within the coverage area.
- Enter AC code. Press "Next".An information text "Protection on?" appears.
- **4.** Select "Yes" if the new system needs to be protected. It is not possible to delete a protected subscription from the System menu<sup>1</sup>.
- **5.** Press "OK". A searching mode starts.

#### Unsubscribe System

- 1. Select "Unsubscribe"<sup>1</sup>.
- 2. Select the system to unsubscribe in the list.
- 3. Press "Select".
- 4. Press "Yes" to unsubscribe the system. Otherwise, press "No".

#### Rename System

You can change the name of the system in the handset.

- 1. Select "Rename System".
- 2. Select the system to rename.
- 3. Press "Edit"
- 4. Enter new name.
- 5. Select "Save".

#### **Priority**

The default order of priority is the order of entered subscriptions. This means that the first subscribed system has the highest priority. This list can be edited by the user. You can set the systems in priority by moving them up or down in the list.



**Note:** This is used in combination with system set to be "Automatic". See "Change System" on page 36.

- 1. Select "Priority".
- 2. Change the priority if required by selecting "Up" or "Down". The priority will be saved when "Back" is selected.

<sup>1.</sup> It is not possible to unsubscribe a protected system via the System menu. The unsubscribtion must be made via the Admin menu or the DECT system.

# **Advanced Functions**

## Admin Menu

The handset has a hidden menu for system administrators. See the *Mitel 5603 Wireless Handset Configuration Manual*.

The Admin menu contains:

- Software and hardware information, licence information, IPEI/IPDI, and User ID
- DECT link and system information
- Fault logging
- Centralized Management status
- Enhanced system menu with ability to alter protection
- · Factory reset option

For quick access to the **D**evice **I**nformation (DI) menu in idle mode, press the keys containing \*#**DI**# (that is \*#34# ). To view the IPEI/IPDI directly, press \*#06#. See the table below

Information	Code
Software version	*#34#
Hardware version	*#34#
IPEI/IPDI	*#34# or *#06#
User ID	*#34#

# Clear Lists in Charger

Via PDM/WSM you can set a parameter that will clear messaging lists and call lists that have been stored in the handset. When the parameter is activated and the function has been downloaded to the handset, the lists will be deleted when placed in a charger. This can be useful during administration of handsets for new users. See also the *Mitel 5603 Wireless Handset Configuration Manual*.

# System Handling

# Software Upgrade and Additional Features

Software and options in the 5603 handset can be upgraded by using the PDM or the WSM. See the *Portable Device Manager (PDM) Installation and Operation Manual* or the *WSM Installation and Operation Manual*.

Examples of additional features that can be downloaded/configured via PDM/WSM:

- Company phonebook
- Downloadable languages

Refer to the Mitel 5603 Wireless Handset Configuration Manual for more information.

To view the handset's software version, enter \*#34# in standby mode.

# Troubleshooting

This section contains information on how to solve common operational problems, and warnings you may receive.

Go through the following lists if you encounter any problems. If this checklist does not solve the problem, contact your system administrator.

If others have similar problems, there may be a system error.

## Operational Problems

Fault	Probable cause	Action or comment
No display	The battery level is low or the handset is defective.	Charge the battery or contact system administrator.
No ringing	The sound off icon is on, or ringer volume set to silent, or the handset is defective.	Long press the Sound off key, or increase volume, or contact system administrator.

# Error or Warning Messages

Display shows	Probable cause	Action or comment
No access	The network is in range, but no access rights.	Switch handset off and then switch it on again or contact system administrator.
No System. The handset beeps once a minute (during max 30 minutes) with a low tone followed by a high tone (if enabled, the vibrator also follows the beeps).	The handset is out of coverage or handset is defective.	Stop the beep with the Sound off key and go into range. Note: When re-entering the coverage area it can take a couple of minutes before the handset automatically has registered into the system. or contact system administrator.
SERVICE required options corrupt	The handset is defective.	Select reset option on the middle soft key if available or if no reset option is available or fault does not resolve the handset needs repair. Note: Display message only shown in English.
SERVICE required Invalid IPDI Note: This display message is only shown in English.	Easy replacement procedure not followed correctly or failure during easy replacement procedure.	Send the handset for service.
		Page 1 of 2

Display shows	Probable cause	Action or comment
Enter PIN code	The handset's lock is activated.	Enter the required PIN code. If PIN code lost enter new via PDM or do a factory reset via PDM.
Battery low, charge now	The battery level is low.	Charge or replace the battery.
Phonebook is not available at the moment.	The phonebook does not respond, not available at the moment.	Try again later or if fault persists do a factory reset via admin menu or PDM.
Voice mail number not defined	There is no Voice mail number defined in the handset.	Define a Voice mail number via PDM.
Could not encrypt connection	The parameter "Encryption Required" is enabled in the handset in combination with;	Disable the "Encryption     Required" parameter in     handset; and/or,
	Unencrypted base station(s);     and/or,	Enable the encryption in the base station(s); and/or,
	2. Unsupported base station(s).	<b>Note:</b> If base station(s) is used, the software version must be 3.1.x or later.
		Use supported base station(s).     Ask your supplier.
		Page 2 of 2

#### **LED Error Indications**

See also chapter "LED Indications during Easy Replacement" on page 47.

LED is flashing red, quick flash, (100 ms on, 800 ms off)

- 1. If a third handset, that is another handset than the "old" (the replaced handset) and "new" (the replacement headset) handset, is inserted into the charger during Easy Replacement, this error indication appears. Change to the correct handset.
- 2. The charger has found that Easy Replacement does not work. Change back to the "new" handset.

LED is flashing red, long flash (800 ms on, 100 ms off)

Error during Easy Replacement. Both telephones need to be sent for service.

# **Operation Notice**

# Accessibility and Voice Quality

The base network is not always available. If you do not get in contact with your system, contact your system administrator. For best voice quality, avoid positioning near computer, radio or similar equipment.

## Operating Area

You can only use your handset in the area that is covered by your system. Outside this area you will loose contact with the system. The signal strength icon will be low and "Searching" will be displayed.

#### Out of Range

When you leave the system's coverage area a short beep will sound and the text "Searching" will appear in the display.

The out of range beep will be repeated every minute for 30 minutes. You can turn

the sound off by long pressing #.

When re-entering the coverage area it can take a couple of minutes before the handset automatically has registered into the system.

# Maintenance

#### Maintenance of Batteries

## **Battery Warnings**

Ō	The "Low battery" icon appears when the battery has 10% or less remaining capacity left. In addition; a warning signal sounds every minute, the LED flashing orange, and the window "Battery low. Charge now." appears.
Ō	The "Empty battery" icon is flashing when the battery has 5% or less remaining capacity left. In addition; a warning signal sounds every second, the LED flashing red, and the window "Battery empty. Shutting down." appears.

During a call, only the corresponding battery warning signal will notify the user. The warning signal cannot be silenced during a call. When not in call, the warning signal can be silenced by pressing \*\*.

# Charge the Battery

Place the handset in the desktop charger or in the rack charger. The battery is being charged when the LED on the handset is steady orange. When the battery is fully charged the LED will be green.

An animated battery icon is also shown in the display indicating charging by starting with its current charge and ending with the full charge. A filled battery icon imindicates a fully charged battery.



Note: Only use the prescribed chargers for charging.

#### Replace the Battery

If the standby time for the handset becomes too low, the battery should be replaced by a new one. Please contact your system administrator or your supplier, for information about new batteries. Attach the battery as described in the illustration below. The battery is easy to replace. It is attached inside the battery lid and is connected to the handset in such a way that no miss-contact is possible.



Figure 8: Easy Replaceable Battery

# Attach the Hinge-type Clip

Attach the hinge-type belt clip as described in the illustration below.




Figure 9: Attach the Hinge-type Clip into Position

# Attach the Swivel-type Clip

Attach the swivel-type belt clip as described in the illustration below.




Figure 10: Attach the Swivel-type Clip into Position

# Easy Replacement

Easy replacement can be used if a handset needs to be replaced. The easy replacement procedure is done via the handset display and the 5607 Programmer, or the rack charger.



**Note:** If the electrical connection is damaged, it is not possible to follow the Easy Replacement procedure. Depending on fault, it might work to do a replacement via PDM/WSM. See the *Mitel 5603 Wireless Handset Configuration Manual*.

The easy replacement procedure is done via the handset display and the 5603/4 Programmer or the 5603/4 Rack Charger.

The following settings are replaced during easy replacement:

- DECT registration
- User options (including User ID)
- Contacts
- The extension number is assigned to the new handset

The following settings are not replaced during the easy replacement:

Call list

# Before Starting Easy Replacement Procedure

1. Check that both the old handset (that is, the handset to be replaced) and the new handset (that is, the replacement handset) are of the same device type (5603).



**Note:** You can perform Easy Replacement between different product licenses (that is; Basic and Advanced). The new handset's product license is not replaced by the old handset's variant license during the procedure<sup>1</sup>.

- 2. Make sure that the handset batteries are charged before starting the easy replacement procedure.
- 3. Switch off the **new** handset by long pressing of

#### Easy Replacement Procedure

During the Easy Replacement procedure, the LEDs of the handset and the charger follow the same LED indications. This means that if the old handset has a broken display, the LED indications on the charger and on the handset can be used to follow the replacement procedure. Before and after easy replacement the LEDs may have different LED indications. For more details. See also "LED Indications during Easy Replacement" on page 47.

IMPORTANT: Never remove a handset from the charger until the instructions in the display or the LED tells you to do so (see status on the LED if the display is broken). If an error is indicated you may want to remove the handset. See "Troubleshooting" on page 40 for further instructions.

After you place the old handset in the charger, you must place the new handset in the charger, regardless of whether the replacement was successful or not. Failing to do so may result in malfunction and the new handset will need servicing.




Figure 11: Easy Replacement Procedure using the 5603 Programmer

1	On the <b>new</b> handset, press and hold
	Note: Do not release until you are instructed to do so.
2	Put the new handset in the charger.
3	When the text "Start phone replacement?" appears, release .
	Press "Yes" (left soft key).
	The text "Follow the instructions. Each step can take several minutes." appears in the display. Press "OK" (left soft key).
4, 5	When the text "Please insert old phone in charger" appears, replace the new handset with the <b>old</b> handset. The handset can either be switched on or off.
	<b>Note:</b> If the rack charger is used, the <b>same</b> charging slot has to be used for both handsets.
	The handset will be restarted and after a few seconds, the text "Saving settings. Do not remove phone from charger" appears. The charger LED changes to slow orange flashing.
the ch	RTANT: If the old handset cannot communicate with the charger, put the new handset in narger to restore its settings (that is, the handset's IPDI). If this step is not performed, the nandset must be sent for service. The old handset's settings might be transferred to the nandset by using PDM. See the handset's Configuration Manual.
6, 7	When the text "Please insert new phone in charger" appears, replace the old handset with the <b>new</b> handset. The text "Restoring settings" appears.
IMPO	RTANT: Do not remove the handset while the text "Restoring settings" appears.
8	When the text "Phone successfully replaced. Please remove phone to restart." appears in the display, remove the handset from the charger. The handset is automatically restarted.

## LED Indications during Easy Replacement

The following table shows the LED indications that are used for the 5603 and the charger during the easy replacement procedure. See also "Troubleshooting" on page 40.

LED indication	Description
Orange, flashing (1 000 ms on, 1 000 ms off)	File transfer during Easy Replacement.
Orange, flashing (100 ms on, 800 ms off)	"Change phone" indication during Easy Replacement.
Red, flashing (100 ms on, 800 ms off)	Error indication during Easy Replacement. Put back old portable in charger.
Red, flashing (900 ms on, 100 ms off)	Error during Easy Replacement. Service required for both portables.

# **Related Documents**

- Mitel 5603 Wireless Handset Configuration Guide
- Installation and Operation Manual, WSM for Mitel
- Installation and Operation Guide, Portable Device Manager (PDM), Windows Version

Index	IVI
	Menu tabs 8
	Microphone 3
A	Mute button 9
Antenna 3	
	N
В	Navigation Key 9
Battery 3, 43	Number input mode 10
low battery 43	·
	0
C	On/Off button 9
C (Clear) button 9	Operating Area 42
Call info 8, 20, 25	Out of Coverage 42
Calling	3
answered call 8	P
call a number from the call list 14	PIN code 34
dial a number 14	1 6545 61
missed call 8	R
outgoing call 8	Ring signal muted 7
quick call by a name in the phonebook 14	Ting signal mated 7
Case 3	S
Centralized phonebook 23	Signal strength 7
Clip 3	Speed dial 10
	Standby mode
E	date 7
Earpiece 3	time 7
	user identity 7
H	user identity T
Handsfree key 1	Т
	Text input mode 10
I .	rext input mode 10
Icons 7	W
L	Writing Text/Numbers
LED indications 47	add space in text 10
Loudspeaker 3	pause 10 upper/lower case 10
Loudspeaking 8, 15	upper/lower case it

Fax: +1(613) 592-4784

Fax: +1(480) 961-1370

Fax: +44(0)1291-430400 Fax: +1(613) 592-7825 Fax: +61(0) 2 9023 9501

www.mitel.com



# For more information on our worldwide office locations, visit our website at www.mitel.com/offices

THIS DOCUMENT IS PROVIDED TO YOU FOR INFORMATIONAL PURPOSES ONLY. The information furnished in this document, believed by Mitel to be accurate as of the date of its publication, is subject to change without notice. Mitel assumes no responsibility for any errors or omissions in this document and shall have no obligation to you as a result of having made this document available to you or based upon the information it contains.

M MITEL (design) is a registered trademark of Mitel Networks Corporation. All other products and services are the registered trademarks of their respective holders.

© Copyright 2011, Mitel Networks Corporation. All Rights Reserved.